



JIMMYJANE

Sell Sheets - 2024

European Version

---

# JIMMYJANE REIMAGINED

---

Elevate Your Intimate Experience With Our Electrifying  
Collection of Innovative Pleasure Products!



Since its inception in 2004, **JIMMYJANE** has revolutionized the landscape and perception of sexual well-being. Built on the belief that pleasure is a source of power and that well-designed products contribute to overall well-being, we have consistently shown a commitment to innovation. By merging sophisticated product development with proprietary technology, we strive for a future where sensuality and technology converge seamlessly.

**JIMMYJANE** believes in the uniqueness of each individual's sexuality, designing products that encourage exploration and interpretation rather than dictating what is considered sexy. Celebrating our 20th anniversary in 2024, we reflect on a journey marked by creativity and a dedication to elevating intimate experiences.

As we enter our third decade, we stand as a guiding light of innovation in the adult industry, continuing to shape the future of pleasure with a rich legacy behind, and an exciting journey ahead. Our latest product launch seamlessly merges cutting-edge technology with sophisticated design, promising to redefine and elevate intimate experiences. We appreciate your interest in the brand, and we look forward to building our partnership with you for many years to come. As always, our commitment remains unwavering in delivering outstanding products and services. **After all—Your Pleasure is Our Passion!**



**We are proud to announce a shift to using packaging certified by the Forest Stewardship Council (FSC).**

Renowned for our avant-garde design, **JIMMYJANE** is proud to announce a shift to exclusively using FSC Certified packaging, aligning our products with environmentally responsible practices.

# JIMMYJANE





## FORM 2<sup>®</sup> PRO

The best seller in pleasure is back—and more powerful than ever. Featuring a new magnetic USB charging cord with five vibration modes and five intensity levels, the Form 2<sup>®</sup> Pro's dual-motor design will powerfully massage, stimulate, and tease your clitoris, reaching new levels of euphoric climax.

### KEY PRODUCT FEATURES

- Multi-award-winning design
- The unique, flexible design surrounds sensitive areas with concentrated vibrations
- Dual-motors offer powerful, fulfilling vibrations
- Choose from 25 vibration modes—5 vibration patterns with 5 intensity levels per pattern (5 x 5)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 60-minute run time / 90-minute charge time
- Waterproof: fully submersible and bath-friendly
- Features a discretionary travel-lock
- Made with hygienic silicone and stainless steel
- Easy 3-button operation
- 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Form 2 Pro should be locked, but if you see a flashing light when a button is pressed, follow the steps below to unlock the device.

**Unlock** - Press the power & "+" buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting the FORM 2 Pro to a powered charging cable will unlock it.

**Lock** - Press the power & "+" buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Power ON** - Press and hold the power button for three seconds to turn on the FORM 2 Pro. The LED will turn on for 3 seconds and then turn off—the massager will begin to vibrate in the constant vibration mode at medium speed.

**Changing Modes / Speeds** - Press the power button to cycle through the 5 vibration modes. The LED will turn on for 3 seconds, slightly mimic the current vibration mode, and then the LED will turn off.

Press "+" button to increase the speed on each mode. The LED will get slightly brighter, and will turn off after three seconds.

Press "-" button to decrease the speed on each mode. The LED will get slightly dimmer, and will turn off after three seconds.

**Power OFF** - Press and hold the power button (middle button) for three seconds to turn off the FORM 2.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) FORM 2<sup>®</sup>, (1) Travel Pouch, & (1) USB Charging Cord

#### PINK



SKU	JJ10901
UPC	840281300907



#### SLATE



SKU	JJ10904
UPC	840281300006



### PRODUCT INFO

PRODUCT SPECS
Length: 3 in. (7.5 cm)
Width: 1.8 in. (4.5 cm)
Ear Length: 1.3 in. (3.2 cm)
Ear Diameter: 0.6 in. (1.5 cm)
PACKAGE SPECS
Width: 3.9 in. (10 cm)
Height: 7.5 in. (19.1 cm)
Depth: 2.2 in. (5.6 cm)
Weight: 6.2 oz. (175 g)
CARTON SPECS
24 pcs per carton
Width: 16.6 in. (42.2 cm)
Height: 8.4 in. (21.3 cm)
Depth: 13.8 in. (35 cm)
Weight: 14.6 lbs. (6.6 kg)

MODES
Modes: 5 x 5
IP RATING
IPX7
MATERIALS
Silicone & Stainless Steel
POWER SOURCE
Rechargeable Lithium Battery (USB + Magnetic Charging)
CHARGING INFO
Run Time: 60 min.
Charge Time: 90 min.

### TESTERS AVAILABLE!

Tester Includes:  
Full Product +  
Informational  
Table Tent

PINK	SLATE
SKU	JJ10901TE
UPC	840281325061
SKU	JJ10904TE
UPC	840281302505



RECYCLABLE - FSC CERTIFIED MIX PACKAGING



## APEX®

The Apex® is our best seller for a reason—it has everything you're looking for and more! First the silky-soft tongue is a toe-curling oral sex simulator that features seven patterns of simultaneous licking and vibration. Next, the 3-speed suction mode gently pulls and releases on your sensitive areas increasing blood-flow and bringing them close to the licking tongue. Finally, the curved handle contains a high-powered 10-function vibrating motor perfect for internal g-spot or anal pleasure, or external clitoral, nipple, and muscle stimulation. The silky-soft hygienic silicone handle and tongue feel great to the touch, and quickly adjust to body temperature.

When you want to go from vaginal play to nipple play, quickly switch the silicone rimmed cups and get back to the action! The high-performance, rechargeable battery controls the four powerful internal motors and stays strong from beginning to end. New to suction stimulation? Fear not! The Apex® also features a quick-release button that allows you to stop all suction immediately.

### KEY PRODUCT FEATURES

- Multi-award-winning design
- A four-in-one pleasure package—Suction, licking + vibration, and handle vibration can be used to stimulate the clitoris, nipples, g-spot, anus, and more with concentrated sensations.
- 7 Powerful tongue licking + vibration modes—3 intensity levels and 4 patterns (3 + 4)
- 3 Intense "suck-and-release" power levels offer heightened pleasure by pulling sensitive areas close to the licking tongue.
- Vibrating handle can be used externally, as well as internally, and offers 10 vibration mode—3 intensity levels and 7 patterns (3 + 7)
- Quick release button allows you to quickly release the suction when desired
- Includes two cup attachments—The oval cup envelops the vulva, while the round cup encompasses the nipples (or even the head of a penis). The silky-soft silicone rims on both cups add a soft touch and help to ensure an air-tight seal
- Includes two textured tongue sleeves designed to tickle and tease
- Splashproof • Easy 4-button operation • 1-Year limited warranty



SKU	JJ40026
UPC	840281300884



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 10.2 in. (25.8 cm) Width: 1.7 in. (4.2 cm) Depth: 1.7 in. (4.3 cm) Insertable (L): 4.8 in. (12.2 cm) Insertable (D): 1.4 in. (3.5 cm)	7 Tongue Patterns, 10 Handle Vibration Patterns 3 Suction Levels
PACKAGE SPECS	IP RATING
Width: 5 in. (12.7 cm) Height: 11 in. (28 cm) Depth: 2.8 in. (7 cm) Weight: 16.2 oz. (460 g)	IPX4
CARTON SPECS	MATERIALS
24 pcs per carton Width: 24.8 in. (63 cm) Height: 13 in. (33 cm) Depth: 18.1 in. (46 cm) Weight: 29.3 lbs. (13.3 kg)	Silicone, Stainless Steel, Polycarbonate, ABS, TPE
POWER SOURCE	CHARGING INFO
Rechargeable Lithium Battery (USB + Magnetic Charging)	Run Time: 60 min. Charge Time: 90 min.

### TESTER AVAILABLE!



**Tester Includes:**  
Full Product +  
Informational  
Table Tent

SKU	JJ40026TE
UPC	840281325078



### USAGE INSTRUCTIONS

- Note** - When first received, the Apex should be locked. To unlock the device:
- Unlock** - Press the tongue & suction buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting the Apex to the powered charging cable will unlock it.
- Lock** - Press the tongue & suction buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.
- Power ON** - Press the tongue, suction, or handle vibration buttons to activate the desired mode. The LED will turn on, stay lit, and will blink to indicate the current mode.
- Changing Modes / Speeds** - Press the tongue, suction, or handle vibration buttons to cycle through modes. The LED will turn on and mimic the current vibration mode.
- Power OFF** - Press and hold the tongue, suction, or handle vibration buttons for 3 seconds to turn off.
- Quick Release** - To quickly release suction at any time, press and hold the suction release button. (Third button from the tongue)

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

- (1) Apex®, (1) Vaginal Cup, (1) Nipple Cup, (2) Sleeves, (1) Travel Pouch, & (1) USB Charging Cord





## REFLEXX™ RABBIT 1

The unique spring-like u-shape design of the Reflexx™ Rabbit 1 is more than just for looks—it's designed to hug your pelvic region and deliver the perfect amount of pressure. The curved shape and elongated handle allow you to comfortably move the massager to a multitude of angles, reaching the perfect spot every time. Both your g-spot and clitoris will be simultaneously sent into overdrive from the ultra-powerful, dual, independently controlled vibrating motors. Want to take it to the next level? Indulge in the luxuriating "warming mode." Sit back, relax, and enjoy the warm embrace of the Reflexx™ Rabbit 1, even on the chilliest of days!

### KEY PRODUCT FEATURES

- Ultra-powerful, dual, independently controlled, motors offer intense vibrations
- The unique, Reflexx™ action hugs the pelvic region, applying the perfect amount of pressure to stimulate the g-spot and clitoris simultaneously
- Warming mode brings the massager above body temperature in a few minutes
- Ergonomically designed handle increases your reach up to 6 inches
- Choose from 10 vibration modes per motor—3 intensity levels and 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-minute run time / 4-hour charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock
- Made with hygienic silicone and ABS plastic
- Easy 3-button operation
- 1-Year limited warranty

### USAGE INSTRUCTIONS

**Note** - When first received, the Reflexx Rabbit 1 should be locked. Follow the steps below to unlock.  
**Unlock** - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.  
**Lock** - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.  
**Power ON** - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn on the desired mode. The LED will turn on, stay lit, and will blink to indicate the current mode.  
**Changing Modes / Speeds** - Press the G-Spot vibration or Clitoral vibration buttons to cycle through the 10 vibration functions. The LED will turn on, stay lit, and will blink to indicate the current mode. (Warming function has only one mode).  
**Power OFF** - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn off. The LED will turn off.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Reflexx™ Rabbit 1, (1) Travel Pouch, & (1) USB Charging Cord

SKU	JJ10303
UPC	840281301829



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 6.6 in. (16.9 cm)	10 Vibration Patterns (3 + 7)
Width: 3.3 in. (8.3 cm)	1 Warming Mode
Depth: 1.7 in. (4.2 cm)	IP RATING
Insertable (L): 3.7 in. (9.5 cm)	IPX7
Insertable (D): 1.3 in. (3.4 cm)	MATERIALS
PACKAGE SPECS	Silicone, ABS Plastic
Width: 5 in. (12.7 cm)	POWER SOURCE
Height: 9.1 in. (23 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Depth: 2.8 in. (7 cm)	CHARGING INFO
Weight: 14.5 oz. (412.2 g)	Run Time: 45 min.
CARTON SPECS	Charge Time: 4 hours
24 pcs per carton	
Width: 15.7 in. (40 cm)	
Height: 11.6 in. (29.5 cm)	
Depth: 18.8 in. (47.7 cm)	
Weight: 23.4 lbs. (10.6 kg)	

### TESTER AVAILABLE!

Tester Includes:  
Full Product + Informational Table Tent

SKU	JJ10303TE
UPC	840281325139



RECYCLABLE - FSC CERTIFIED MIX PACKAGING







## REFLEXX™ RABBIT 3

The unique, spring-like, curved design of the Reflexx™ Rabbit 3 is more than just for looks—it's designed to be reactionary to your movements. The internal steel band comes alive, reacting to the pressure that you apply, driving the powerful head vibrations deep down. This "Reflexx" action creates a one-of-a-kind experience, allowing you to move and press the massager to a multitude of angles to reach the perfect spot every time. Both your g-spot and clitoris will be simultaneously sent into overdrive from the dual independently controlled vibrating motors.

Want to take it to the next level? Indulge in the luxuriating "warming mode." Sit back, relax, and enjoy the warm embrace of the Reflexx™ Rabbit 3, even on the chilliest of days!

### KEY PRODUCT FEATURES

- Dual independently controlled motors allow you to personalize your pleasure
- The unique, spring-like Reflexx™ action is reactionary to your movements—flexing when pressure is applied or released, giving the perfect amount of pressure.
- Warming mode brings the massager above body temperature in a few minutes
- Choose from 10 vibration modes per motor—3 intensity levels and 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-minute run time / 3-hour charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock
- Made with hygienic silicone and ABS plastic
- Easy 3-button operation
- 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Reflexx Rabbit 3 should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.

**Lock** - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Power ON** - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn on the desired mode. The LED will turn on, stay lit, and will blink to indicate the current mode.

**Changing Modes / Speeds** - Press the G-Spot vibration or Clitoral vibration buttons to cycle through the 10 vibration functions. The LED will turn on, stay lit, and will blink to indicate the current mode. (Warming function has only one mode).

**Power OFF** - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn off. The LED will turn off.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Reflexx™ Rabbit 3, (1) Travel Pouch, & (1) USB Charging Cord

SKU	JJ10305
UPC	840281301843




### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 9 in. (23 cm)	10 Vibration Patterns (3 + 7)
Width: 3.4 in. (8.7 cm)	1 Warming Mode
Depth: 1.4 in. (3.6 cm)	IP RATING
Insertable (L): 5.3 in. (13.7 cm)	IPX7
Insertable (D): 1.3 in. (3.4 cm)	MATERIALS
PACKAGE SPECS	Silicone, ABS Plastic
Width: 5 in. (12.7 cm)	POWER SOURCE
Height: 9.1 in. (23 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Depth: 2.8 in. (7 cm)	CHARGING INFO
Weight: 12.3 oz. (350 g)	Run Time: 45 min.
CARTON SPECS	Charge Time: 3 hours
24 pcs per carton	
Width: 15.5 in. (39.3 cm)	
Height: 11.6 in. (29.5 cm)	
Depth: 22.8 in. (58 cm)	
Weight: 20.2 lbs. (9.2 kg)	

### TESTER AVAILABLE!

Tester Includes:  
Full Product +  
Informational  
Table Tent

SKU	JJ10305TE
UPC	840281325092



RECYCLABLE - FSC CERTIFIED MIX PACKAGING



## HELLO TOUCH® PRO

Easily turn your fingertips into powerful pleasure devices. Simply pinch the base, and direct the silicone tip towards all of those spots that are yearning for attention, or slip the massagers into the silky-soft silicone finger sleeves and get creative with yourself or with a partner. That's not all—the travel case doubles as a rechargeable wireless remote, putting all the power in you, or your partner's, (free) hand.

When the fun is done, slide the massagers back into the travel case, and they'll be fully charged when it's time to play again.

### KEY PRODUCT FEATURES

- Two mini finger massagers that pack a real punch
- Powered case charges the massagers while stored
- Rechargeable case doubles as a wireless remote for full control
- Includes two silicone sleeves that easily attach to your fingertips
- Case and massagers are USB rechargeable with the included magnetic charging cord
- High-performance battery: Massager: 25-min. run time / 90-min. charge time / Travel Case: 120-min. charge time
- Splashproof • Made with hygienic silicone and ABS plastic
- 1-Year limited warranty • Easy 1-button operation

### USAGE INSTRUCTIONS

**Standby Mode ON** - Press and hold the power button on the bottom of the massager for three seconds to enter standby mode. The LED will turn on.

**Power ON / Changing Modes / Speeds** - Press the power button on the massagers or the remote case to cycle through the 10 vibration modes.

**Power OFF** - Press and hold the power button on the bottom of the massager or the remote case for three seconds to power off. The LED will turn off.

**Standby Mode OFF** - To turn standby mode off, press and hold the power button on the bottom of the massager for 3 seconds or insert the massagers into the remote case.

**Charging Instructions** - Both the massagers and the case can be charged with the magnetic charging cord. The remote case can recharge the massagers up to 2 times.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Hello Touch Pro® Remote Case, (2) Massagers, (2) Silicone Finger Sleeves, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10525
UPC	840281301928



### PRODUCT INFO

PRODUCT SPECS	MODES
Case Width: 2 in. (5.2 cm)	Modes: 10
Case Height: 3 in. (7.5 cm)	IP RATING
Case Depth: 1 in. (2.7 cm)	IPX6
Vibe Height: 2.4 in. (6.2 cm)	MATERIALS
Vibe Dia.: 0.7 in. (1.8 cm)	Silicone & Stainless Steel
PACKAGE SPECS	POWER SOURCE
Width: 3.9 in. (10 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Height: 7.5 in. (19.1 cm)	CHARGING INFO
Depth: 2.2 in. (5.6 cm)	Vibe Run Time: 25 min.
Weight: 7.1 oz. (200.8 g)	Vibe Charge Time: 90 min.
CARTON SPECS	Case Charge Time: 120 min.
24 pcs per carton	
Width: 12.4 in. (31.5 cm)	
Height: 9.6 in. (24.5 cm)	
Depth: 15.6 in. (39.5 cm)	
Weight: 11.6 lbs. (5.3 kg)	

### TESTER AVAILABLE!

Tester Includes:  
Full Product +  
Informational  
Table Tent

SKU	JJ10525TE
UPC	840281325122







SKU	JJ10551
UPC	840281301850



**PRODUCT INFO**

PRODUCT SPECS	MODES
Length: 6.6 in. (16.9 cm) Width: 3.3 in. (8.3 cm) Depth: 1.7 in. (4.2 cm) Insertable (L): 3.7 in. (9.5 cm) Insertable (D): 1.3 in. (3.4 cm)	10 Vibration Patterns (3 + 7) (Per Motor) 3 Come Hither Speeds
PACKAGE SPECS	IP RATING
Width: 5 in. (12.7 cm) Height: 9.1 in. (23 cm) Depth: 2.8 in. (7 cm) Weight: 12.3 oz. (349 g)	Pulsus: IPX7 Remote: IPX4
CARTON SPECS	MATERIALS
24 pcs per carton Width: 15.8 in. (40 cm) Height: 11.6 in. (29.5 cm) Depth: 18.8 in. (47.7 cm) Weight: 20.1 lbs. (9.1 kg)	Silicone, ABS Plastic
	POWER SOURCE
	Rechargeable Lithium Battery (USB + Magnetic Charging)
	CHARGING INFO
	Plug Run Time: 45 min. Plug Charge Time: 120 min. Remote Run Time: 10 hrs. Remote Charge Time: 60 min.

**TESTER AVAILABLE!**

Tester Includes:  
Full Product +  
Informational  
Table Tent

SKU	JJ10551TE
UPC	840281325108

# PULSUS™ G-SPOT

The cleverly curved tip of the Pulsus™ G-Spot massager offers a 3-speed “come-hither” fingering motion that rocks the head back and forth, applying and releasing pressure and rubbing the G-spot and clitoris simultaneously. The dual, independently-controlled motors, each featuring ten high-performing vibration modes, are designed to powerfully stimulate your g-spot and clitoris together or solo. It’s a powerhouse of sensations that need to be felt to be believed.

The rechargeable Pulsus™ G-Spot Vibrator is designed with high-quality, super-soft, and phthalate-free silicone, because your health is just as important as your comfort, and you’ll find both here.

**KEY PRODUCT FEATURES**

- 3-Speed “come-hither” fingering motions rock the head back and forth, applying and releasing pressure to the g-spot and clitoris simultaneously
- Dual, independently controlled motors allow you to personalize your pleasure
- Choose from 10 vibration options per motor—3 intensity levels and 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-minute run time / 120-minute charge time
- Waterproof; fully submersible and bath-friendly (Remote is not waterproof)
- Features a discretionary travel-lock
- Made with hygienic silicone and ABS plastic
- Easy 3-button operation
- 1-Year limited warranty

**USAGE INSTRUCTIONS**

Note - When first received, the Pulsus G-Spot should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the g-spot & power buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.

**Lock** - Press and hold the g-spot & power buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Standby Mode ON** - Press and hold the power button on the Pulsus for 3 seconds to enter standby mode. The LED will turn on and stay solid.

**Power ON** - Once in standby mode, press the G-Spot vibration, Clitoral vibration, or come hither (power) buttons on the Pulsus or the remote to turn on the desired mode. The LED will turn on and stay lit. Press each of the buttons to cycle through their functions.

**Power OFF** - Press and hold the G-Spot vibration, Clitoral vibration, or come hither (power) for three seconds to turn off. The LED will turn off.

**Standby Mode OFF** - To turn standby mode off, press and hold the power button on the Pulsus. (The remote can only turn off functionality, not standby mode.)

**CARE INSTRUCTIONS**

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

**PACKAGE INCLUDES**

- (1) Pulsus™ P-Spot, (1) Remote, (1) Travel Pouch, & (1) USB Charging Cord





## DEIMOS®

High-tech pleasure meets intuitive design with our vibrating silicone Deimos® C-Ring. Complete with two powerful vibrating motors (one in each flexible ear) offering 3 intensity levels and 7 vibration patterns for maximum clitoral stimulation. Try out the remote control for spontaneous couples.

### KEY PRODUCT FEATURES

- Two powerful motors, one in each flexible ear
- Choose from 10 vibration modes—3 intensity levels with 7 vibration patterns (3 + 7)
- Waterproof c-ring; fully submersible and bath-friendly (Remote is NOT waterproof)
- C-Ring and remote are both USB rechargeable with the included magnetic charging cord
- High-performance battery: 60-minute run time / 120-minute charge time
- Made with hygienic silicone and plastic
- Easy 1-button operation
- 1-Year limited warranty

### USAGE INSTRUCTIONS

**Standby Mode ON** - Press and hold the power button on the Deimos for 3 seconds to enter standby mode. The LED will turn on and stay solid.

**Power ON** - Once in standby mode, press the button on the Deimos or the remote to turn on. Press each of the buttons to cycle through their functions.

**Power OFF** - Press and hold the power button on the Deimos or remote for 3 seconds to turn off. The LED will turn off.

**Standby Mode OFF** - To turn standby mode off, press and hold the power button on the Deimos (the remote can only turn off functionality, not standby mode).

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Deimos®, (1) Remote, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10705
UPC	840281300730



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 4.1 in. (10.5 cm)	Modes: 10 (3+7)
Width: 2.2 in. (5.5 cm)	IP RATING
Depth: 1 in. (2.5 cm)	Deimos: IPX7
Ear Length: 1.3 in. (3.2 cm)	Remote: IPX4
Ear Diameter: 0.6 in. (1.5 cm)	MATERIALS
Remote Dia.: 1.5 in. (3.9 cm)	Silicone, ABS Plastic, & Stainless Steel
Remote Depth: 0.5 in. (1.2 cm)	POWER SOURCE
PACKAGE SPECS	Rechargeable Lithium Battery (USB + Magnetic Charging)
Width: 3.9 in. (10 cm)	CHARGING INFO
Height: 7.5 in. (19.1 cm)	Ring Run Time: 60 min.
Depth: 2.2 in. (5.6 cm)	Ring Charge Time: 120 min.
Weight: 6.6 oz. (186.4 g)	Remote Run Time: 10 hrs.
CARTON SPECS	Remote Charge Time: 60 min.
48 pcs per carton	
Width: 15.6 in. (39.5 cm)	
Height: 9.5 in. (24 cm)	
Depth: 24.4 in. (62 cm)	
Weight: 21.4 lbs. (9.7 kg)	

### TESTER AVAILABLE!

Tester Includes: Full Product + Informational Table Tent

SKU	JJ10705TE
UPC	840281325115



RECYCLABLE - FSC CERTIFIED MIX PACKAGING



## MINI CHROMA™

Just because it's a mini doesn't mean it doesn't pack a punch. The Mini Chroma™ features 3 powerful intensity levels, and 7 vibration patterns, safe aluminum and silicone casing, and an easy-to-operate remote control—making it the perfect discreet on-the-go vibrator you need in your rotation.

### KEY PRODUCT FEATURES

- High-performance massager with powerful fulfilling vibrations
- Choose from 10 vibration modes—3 intensity levels and 7 vibration patterns (3 + 7)
- Made with clean, safe, non-porous aluminum and hygienic silicone
- Easy 1-button operation
- Waterproof; fully submersible and bath-friendly (Remote is NOT waterproof)
- Both bullet and remote are USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-minute run time / 120-minute charge time
- 1-Year limited warranty

### USAGE INSTRUCTIONS

**Standby Mode ON** - Press and hold the power button on the mini Chroma for 3 seconds to enter standby mode. The LED will turn on and stay solid.

**Power ON** - Once in standby mode press the button on the Mini Chroma or the remote to turn on. Press either of the buttons to cycle through the 10 functions. The LED will mimic the mode and then turn off after 3 seconds.

**Power OFF** - Press and hold the button on the Mini Chroma or remote for 3 seconds to stop motor functions.

**Standby Mode OFF** - To turn standby mode off, press and hold the power button on the Mini Chroma. (The remote can only turn off functionality, not standby mode).

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Mini Chroma™, (1) Remote, (1) Travel Pouch, & (1) USB Charging Cord



#### TEAL



SKU	JJ10513
UPC	840281300983



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 3 in. (7.8 cm)	Modes: 10 (3 + 7)
Diameter: 0.7 in. (2 cm)	IP RATING
Remote Dia: 1.5 in. (3.9 cm)	Mini Chroma: IPX7
Remote Depth: 0.5 in. (1.2 cm)	Remote: IPX4
PACKAGE SPECS	MATERIALS
Width: 3.9 in. (9.8 cm)	Aluminum & Silicone
Height: 7.2 in. (18.3 cm)	POWER SOURCE
Depth: 2.1 in. (5.2 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Weight: 8.4 oz. (238 g)	CHARGING INFO
CARTON SPECS	Plug Run Time: 45 min.
24 pcs per carton	Plug Charge Time: 120 min.
Width: 15.1 in. (38.4 cm)	Remote Run Time: 10 hrs.
Height: 6.6 in. (16.8 cm)	Remote Charge Time: 60 min.
Length: 15.5 in. (39.4 cm)	
Weight: 12.1 lbs. (5.5 kg)	







## SOLIS™ FORM 6

The perfectly curved Solis™ FORM 6 is expertly designed to contour to your body, making it the ideal shape for both internal and external stimulation. The hygienic and silky-smooth silicone exterior feels amazing against the skin, and the ergonomic design allows you to hit every pleasure point with ease. The two independently controlled “treble and bass” motors offer powerful, yet unique “stereophonic vibrations” expertly designed for your pleasure. The shaft vibrator (treble) offers soft, yet powerful vibrations that are designed to travel along the internal surface of the vaginal canal, and stimulate the labia and clitoris. While the head vibrator (bass) is designed to offer focused, deep rumbling vibrations desired for G-Spot & pinpoint external stimulations.

The internal warming mode quickly brings the vibrator to just above body temperature, and adds an extra element of pleasure to your experience.

### KEY PRODUCT FEATURES

- Dual motors offer powerful, “stereophonic” vibrations that run at different frequencies
- The ergonomic design surrounds sensitive areas with vibrations
- Independently controlled motors can be used simultaneously or individually for unique stimulation experiences.
- Warming mode brings the massager above body temperature in a few minutes
- Choose from 10 vibration options—3 intensity levels and 7 vibration modes (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-min. run time / 120-min. charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock • Made with hygienic silicone
- Easy 3-button operation • 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Solis FORM 6 should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the head vibration & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice.

**Lock** - Press and hold the head vibration & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Power ON** - Press and hold the head vibration, shaft vibration, or warming buttons for 3 seconds to turn on the desired mode. The LED will turn on and stay lit. Press each of the buttons to cycle through their functions.

**Power OFF** - Press and hold the head vibration, shaft vibration, or warming buttons for 3 seconds to turn on the desired mode. The LED will turn off.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Solis™ FORM 6, (1) Travel Pouch, & (1) USB Charging Cord

SKU	JJ10680
UPC	840281301874



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 8.7 in. (22 cm)	Vibration Modes: 10 (3 + 7)
Width: 1.4 in. (3.6 cm)	(Per Motor)
Depth: 2.6 in. (7 cm)	Warming Mode: 1
Insertable L: 4.9 in. (12.5 cm)	IP RATING
Insertable Dia.: 1.4 in. (3.6 cm)	IPX7
PACKAGE SPECS	MATERIALS
Width: 4.8 in. (12.3 cm)	Silicone & ABS Plastic
Height: 10.5 in. (26.5 cm)	POWER SOURCE
Depth: 3.3 in. (8.5 cm)	Rechargeable Lithium Battery
Weight: 20.3 oz. (576 g)	(USB + Magnetic Charging)
CARTON SPECS	CHARGING INFO
24 pcs per carton	Run Time: 45 min.
Width: 15.25 in. (38.7 cm)	Charge Time: 120 min.
Length: 21.5 in. (54.6 cm)	
Depth: 14 in. (35.6 cm)	
Weight: 34.1 lbs (15.5 kg)	





## SOLIS™ RABBIT

The Solis™ Rabbit is specifically designed to give you a mind-blowing orgasm thanks to its unique combination of rhythm and intensity. The hygienic smooth silicone exterior feels amazing against the skin, and the ergonomic design allows you to hit every pleasure point with ease.

Featuring 3 powerful motors in two separate, independently controlled, “treble and bass” zones, offering powerful (yet unique) “stereophonic vibrations” expertly designed for your pleasure. The shaft and clitoral vibrator (treble) offers soft, yet powerful vibrations that are designed to travel along the internal surface of the vaginal canal, and stimulate the labia and clitoris. The head vibrator (bass) is designed to offer focused, deep rumbling vibrations desired for G-Spot & pinpoint external stimulations. The internal warming mode quickly brings the massager to just above body temperature, and adds an extra element of pleasure to your experience.

### KEY PRODUCT FEATURES

- Three motors offer powerful, “stereophonic” vibrations that run at different frequencies
- The ergonomic design surrounds sensitive areas with vibrations
- Two independently controlled motor zones can be used simultaneously or individually for unique stimulation experiences.
- Warming mode brings the massager above body temperature in a few minutes
- Choose from 10 vibration options—3 intensity levels and 7 vibration modes per zone (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-min. run time / 120-min. charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock • Made with hygienic silicone
- Easy 3-button operation • 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Solis Rabbit should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the head vibration & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice.

**Lock** - Press and hold the head vibration & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Power ON** - Press and hold the head vibration, shaft/ear vibration, or warming buttons for 3 seconds to turn on the desired mode. The LED will turn on and stay lit. Press each of the buttons to cycle through their functions.

**Power OFF** - Press and hold the head vibration, shaft/ear vibration, or warming buttons for 3 seconds to turn on the desired mode. The LED will turn off.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES


(1) Solis™ Rabbit, (1) Travel Pouch, & (1) USB Charging Cord

SKU	JJ10681
UPC	840281301881



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 8.7 in. (22 cm)	Vibration Modes: 10 (3 + 7) (Per Motor Zone)
Width: 1.4 in. (3.6 cm)	Warming Mode: 1
Depth: 2.6 in. (7 cm)	IP RATING
Insertable L: 4.9 in. (12.5 cm)	IPX7
Insertable Dia.: 1.4 in. (3.6 cm)	MATERIALS
PACKAGE SPECS	Silicone & ABS Plastic
Width: 4.8 in. (12.3 cm)	POWER SOURCE
Height: 10.5 in. (26.5 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Depth: 3.3 in. (8.5 cm)	CHARGING INFO
Weight: 21.2 oz. (601 g)	Run Time: 45 min. Charge Time: 120 min.
CARTON SPECS	
24 pcs per carton	
Width: 15.25 in. (38.7 cm)	
Length: 21.5 in. (54.6 cm)	
Depth: 14 in. (35.6 cm)	
Weight: 35.7 lbs (16.2 kg)	





## SOLIS™ ASCEND® 2 PRO

The Solis™ Ascend® 2 Pro is a whirlwind of pleasure packed into a sleek and elegant silicone massager. Our best-selling, flexible, dual-ear design bends and maneuvers to tease and tantalize, providing intense stimulation for explosive orgasms that will leave you trembling with pleasure. With 3-speeds and 7-patterns per ear, plus a warming mode, you can mix things up as the mood strikes you! Relax and ease into all the pleasure that awaits you with the Ascend® 2 Pro.

### KEY PRODUCT FEATURES

- The unique, flexible design surrounds sensitive areas with vibrations
- Independently controlled motors can be used simultaneously or individually for unique stimulation internally or externally
- Warming mode brings the massager above body temperature in a few minutes
- Choose from 10 vibration modes—3 intensity levels with 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 60-minute run time / 90-minute charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock • Made with hygienic silicone
- Easy 3-button operation • 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Solis Ascend 2 Pro should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the top vibration & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice.

**Lock** - Press and hold the top vibration & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Power ON** - Press and hold the left or right ear vibration, or warming buttons for 3 seconds to turn on the desired mode. The LED will turn on and stay lit. Press each of the buttons to cycle through their functions.

**Power OFF** - Press and hold the left or right ear vibration, or warming buttons for 3 seconds to turn on the desired mode. The LED will turn off.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Solis™ Ascend® 2 Pro, (1) Travel Pouch, & (1) USB Charging Cord

SKU	JJ10684
UPC	840281301911



### PRODUCT INFO

#### PRODUCT SPECS

Length: 6.3 in. (16 cm)  
 Width: 1.7 in. (4.2 cm)  
 Depth: 2.3 in. (5.8 cm)  
 Ear Length: 1.6 in. (4 cm)  
 Ear Diameter: 0.8 in. (2 cm)

#### PACKAGE SPECS

Width: 4.9 in. (12.4 cm)  
 Height: 7.5 in. (19.1 cm)  
 Depth: 3.3 in. (8.5 cm)  
 Weight: 14.5 oz. (411 g)

#### CARTON SPECS

24 pcs per carton  
 Width: 15.75 in. (40 cm)  
 Length: 20.5 in. (52.1 cm)  
 Depth: 11 in. (27.9 cm)  
 Weight: 24.7 lbs (11.2 kg)

#### MODES

Vibration Modes: 10 (3 + 7)  
 (Per Motor)  
 Warming Mode: 1

#### IP RATING

IPX7

#### MATERIALS

Silicone & ABS Plastic

#### POWER SOURCE

Rechargeable Lithium Battery  
 (USB + Magnetic Charging)

#### CHARGING INFO

Run Time: 60 min.  
 Charge Time: 90 min.





## SOLIS KYRIOS™

The Kyrios™ prostate massager is designed for endless pleasure possibilities—featuring dual stereophonic vibrating motors that can be used simultaneously or individually and an internal warming mode that brings the massager to just above body temperature in minutes. The ergonomic shape means it will comfortably hit your all your pleasure points—The curved head provides targeted stimulation to the prostate, while the base adds to the pleasure by providing perineum stimulation. The innovative comfort Gripp™ holder is designed to slip effortlessly between your fingers, allowing you to easily angle the massager in a range of positions. The rechargeable, wireless remote means you—or your partner—will have hands-free control over the vibrations. Finally the high quality and hygienic silicone design makes the Kyrios waterproof, so you can explore your deepest desires in the shower or bath.

### KEY PRODUCT FEATURES

- Dual motors offer powerful, “stereophonic” vibrations that run at different frequencies
- The ergonomic design surrounds sensitive areas with vibrations
- Comfortable Gripp™ finger holder for easy, no-slip control
- Independently controlled motors can be used simultaneously or individually for unique stimulation experiences.
- Warming mode brings the massager above body temperature in a few minutes
- Choose from ten vibration options—3 intensity levels and 7 vibration modes (3 + 7)
- Massager and remote are both USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-min. run time / 120-min. charge time
- Waterproof design; fully submersible and bath-friendly (Remote is NOT waterproof)
- Features a discretionary travel-lock
- Made with hygienic silicone
- Easy 3-button operation
- 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Kyrios should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the head vibration (left) & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice.

**Lock** - Press and hold the head vibration (left) & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Standby Mode ON** - Press an hold the power (Middle) button on the Kyrios for 3 seconds to enter standby mode. The LED will turn on and stay solid.

**Power ON** - Once in standby mode, press the head vibration (left), base vibration (right) or warming (power) buttons to turn on the desired mode. The LED will turn on and stay lit. Press each of the buttons to cycle through their functions.

**Power OFF** - Press and hold the head vibration (left), base vibration (right) & warming (power) buttons, or warming buttons for 3 seconds to turn off the desired mode. The LED will turn off.

**Standby Mode OFF** - To turn standby mode off, press and hold the power (Middle) button on the Kyrios for 3 seconds (The remote can only turn off functionality, not standby mode).

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Solis™ Kyrios™, (1) Remote, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10683
UPC	840281301904



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 5.7 in. (14.4 cm)	10 Vibration Patterns (3 + 7) (Per Motor)
Width: 3.9 in. (10 cm)	1 Warming Mode
Depth: 1.7 in. (4.2 cm)	
Insertable (L): 4.3 in. (11 cm)	
Insertable (D): 1.4 in. (3.6 cm)	
PACKAGE SPECS	IP RATING
Width: 4.7 in. (12 cm)	Pulsus: IPX7
Height: 10.3 in. (26.1 cm)	Remote: IPX4
Depth: 2.9 in. (7.3 cm)	
Weight: 18.6 oz. (537 g)	
CARTON SPECS	MATERIALS
24 pcs per carton	Silicone, ABS Plastic
Width: 15.25 in. (38.7 cm)	
Length: 21.5 in. (54.6 cm)	
Depth: 14 in. (35.6 cm)	
Weight: 31.5 lbs (14.3 kg)	
	POWER SOURCE
	Rechargeable Lithium Battery (USB + Magnetic Charging)
	CHARGING INFO
	Plug Run Time: 45 min. Plug Charge Time: 120 min. Remote Run Time: 10 hrs. Remote Charge Time: 120 min.



## PULSUS™ P-SPOT

The cleverly curved tip of the Pulsus™ P-Spot massager features a 10-option vibrating motor as well as a 3-speed “come hither” fingering motion that rocks the head back and forth to send your prostate into overdrive. The base features a 10-mode Hyper-Pulse stimulator that acts like a subwoofer, pulsing, tickling, and teasing your perineum. All of these features can be used together or individually, offering a combination of sensations that need to be experienced...to be believed.

The rechargeable Pulsus™ P-Spot massager is designed with high-quality, super-soft, and non-phthalate silicone, because your health is just as important as your comfort, and you'll find both here.

### KEY PRODUCT FEATURES

- 3-Speed “come hither” fingering motions rock the head back and forth applying and releasing pressure to the P-Spot
- Vibrating head offers 10 vibration options—3 intensity levels and 7 vibration patterns (3 + 7)
- The base offers 10 hyper-pulse stimulation options—3 intensity levels and 7 patterns (3 + 7)
- Both the massager and remote are USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-min. run time / 120-min. charge time
- Waterproof; fully submersible and bath-friendly (Remote is not waterproof)
- Features a discretionary travel-lock
- Made with hygienic silicone and ABS plastic
- Easy 3-button operation
- 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Pulsus P-Spot should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the p-spot & power buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.

**Lock** - Press and hold the p-spot & power buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Standby Mode ON** - Press and hold the power button on the Pulsus for 3 seconds to enter standby mode. The LED will turn on and stay solid.

**Power ON** - Once in standby mode press the P-Spot vibration, Hyper-Pulse, or come hither (power) buttons on the Pulsus or the remote to turn on the desired mode. The LED will turn on and stay lit. Press each of the buttons to cycle through their functions.

**Power OFF** - Press and hold the P-Spot vibration, Hyper-Pulse, or come hither (power) for three seconds to turn off. The LED will turn off.

**Standby Mode OFF** - To turn standby mode off, press and hold the power button on the Pulsus. (The remote can only turn off functionality, not standby mode.)

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Pulsus™ G-Spot, (1) Remote, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10552
UPC	840281301867



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 5.7 in. (14.4 cm)	10 Vibration Patterns (3 + 7)
Width: 3.9 in. (10 cm)	10 Hyper-Pulse Modes (3 + 7)
Depth: 1.7 in. (4.2 cm)	3 Come Hither Speeds
Insertable (L): 4.3 in. (11 cm)	IP RATING
Insertable (D): 1.4 in. (3.6 cm)	Pulsus: IPX7
PACKAGE SPECS	Remote: IPX4
Width: 4.7 in. (12 cm)	MATERIALS
Height: 10.3 in. (26.1 cm)	Silicone, ABS Plastic
Depth: 2.9 in. (7.3 cm)	POWER SOURCE
Weight: 19.7 oz. (559 g)	Rechargeable Lithium Battery (USB + Magnetic Charging)
CARTON SPECS	CHARGING INFO
24 pcs per carton	Plug Run Time: 45 min.
Width: 15 in. (38.1 cm)	Plug Charge Time: 120 min.
Length: 21.5 in. (54.6 cm)	Remote Run Time: 10 hrs.
Depth: 12 in. (30.5 cm)	Remote Charge Time: 60 min.
Weight: 32.9 lbs (14.9 kg)	



## TILLA™ SILICONE DILDO

Our non-phthalate, non-latex silicone dildo features an expertly sculpted curve and large head to stimulate the G-Spot. And because the Tilla™ is non-vibrating, it is completely waterproof—Perfect for fun in the shower or tub!

### KEY PRODUCT FEATURES



- Made entirely with high-quality, silky-smooth, hygienic silicone
- Both ends designed to offer unique sensations
- Great for vaginal, G-Spot, anal, and P-Spot stimulation
- 1-Year limited warranty

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Tilla Silicone Dildo



### PRODUCT INFO

SKU	JJ10520
UPC	840281301089
	

PRODUCT SPECS
Length: 7.9 in. (20 cm)
Width: 2.1 in. (5.3 cm)
Depth: 1.4 in. (3.6 cm)
Insertable Dia.: 1.3 in. (3.4 cm)

PACKAGE SPECS
Width: 3.9 in. (9.2 cm)
Height: 10.2 in. (25.8 cm)
Depth: 2.2 in. (5.6 cm)
Weight: 15.9 oz. (451 g)

CARTON SPECS
12 pcs per carton
Width: 10.7 in. (27.2 cm)
Height: 7.1 in (18 cm)
Length: 14.8 in. (37.8 cm)
Weight: 12.3 lbs. (5.6 kg)

MATERIALS
Silicone



## CANNA™

Meet the wand that does it all (and then some). Designed with pleasure and relaxation in mind; the ultra-powerful motor offers incredibly deep, precise rumbling vibrations to relieve tension, reduce muscle fatigue, and provide unparalleled power to stimulate all of your pleasure points. With 7 high-performance modes and three attachable heads included, the Canna™ Personal Massager offers numerous options to personalize your pleasure.

### KEY PRODUCT FEATURES

- High-performance wand with 3 attachable heads
  - FORM 2® attachment surrounds sensitive areas with concentrated vibrations
  - Nubby attachment offers textured nubs to help work out tension in your muscles
  - Tongue attachment offers pinpointed flickering sensations
- Incredibly deep, precise rumbling vibrations to relieve tension
- Unparalleled power to stimulate all of your pleasure points
- The flexible head contours apply the perfect amount of pressure
- The 8-inch length easily reaches from your head to your toes
- Great for clitoral, nipple, and full-body stimulation
- Choose from 7 vibration modes—3 intensity levels with 4 vibration patterns (3 + 4)
- Designed with super-soft phthalate-free, latex-free silicone
- Easy 1-button operation
- Splashproof
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 60-minute run time / 120-minute charge time
- 1-Year limited warranty

### USAGE INSTRUCTIONS

**Power ON** - Press and hold the power button for three seconds to turn on.

**Changing Modes / Speeds** - Press the power button to cycle through the 7 vibration functions.

**Power OFF** - Press and hold the power button for three seconds to turn off.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Canna™, (1) FORM 2® Attachment, (1) Nubby Attachment, (1) Tongue Attachment, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10504
UPC	840281300396



### PRODUCT INFO

PRODUCT SPECS	CARTON SPECS
Length: 8.6 in. (21.8 cm)	24 pcs per carton
Head Dia: 1.7 in. (4.3 cm)	Width: 14.8 in. (37.6 cm)
Handle Dia: 3.3 in. (8.3 cm)	Height: 10.6 in. (26.9 cm)
<b>FORM 2 Attachment</b>	Length: 19.3 in. (49 cm)
Length: 2.5 in. (6.4 cm)	Weight: 14.3 lbs. (6.5 kg)
Diameter: 1.6 in. (4 cm)	
<b>Nubby Attachment</b>	
Length: 1.9 in. (4.9 cm)	<b>MODES</b>
Diameter: 1.9 in. (4.7 cm)	7 Vibration Patterns (3 + 4)
<b>Tongue Attachment</b>	<b>IP RATING</b>
Length: 3.3 in. (8.5 cm)	IPX6
Diameter: 1.6 in. (4 cm)	<b>MATERIALS</b>
	Silicone, ABS Plastic
<b>PACKAGE SPECS</b>	<b>POWER SOURCE</b>
Width: 4.7 in. (12 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Height: 10.3 in. (26.1 cm)	<b>CHARGING INFO</b>
Depth: 2.9 in. (7.3 cm)	Run Time: 60 min.
Weight: 22.7 oz. (644 g)	Charge Time: 120 min.





## EXONA®

The Exona® is as powerful as it is sleek. Designed with a high-tech, flexible head, this one-and-done ergonomic wand has simple, intuitive controls with 5 vibration modes and 3 intensity levels per mode for the pleasurable exploration you deserve.

### KEY PRODUCT FEATURES

- High performance wand with motor that delivers deep, rumbling vibrations
- Choose from 15 vibration modes—5 vibration patterns with 3 intensity levels per pattern (5 x 3)
- Petite handle means this wand is lighter than most, and makes it incredibly easy to hold as well as maneuver into a multitude of positions
- Flexible neck applies the right amount of pressure where it's needed most
- Simple, intuitive controls
- Designed with super soft phthalate-free, latex-free silicone
- Splashproof
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 90-minute run time / 120-minute charge time
- 1-Year limited warranty

### USAGE INSTRUCTIONS

**Power ON** - Press and hold the power button for three seconds to turn on. The LED will light and stay on.

**Changing Modes** - Press the power button to cycle through the 5 vibration functions.

**Changing Speeds** - Press the "+" or "-" buttons to control the speed.

**Power OFF** - Press and hold the power button for three seconds to turn off. The LED will turn off.

### CARE INSTRUCTIONS

Spray JimmyJane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Exona®, (1) Travel Pouch, & (1) USB Charging Cord

SKU	JJ10507
UPC	840281300860



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 7.2 in. (18.3 cm)	15 Vibration Patterns (5 x 3)
Head Dia: 2.6 in. (6.6 cm)	IP RATING
Head Height: 2.8 in. (7 cm)	IPX6
Handle L: 3.6 in. (9.2 cm)	MATERIALS
Handle Dia: 1.6 in. (4 cm)	Silicone, ABS Plastic
PACKAGE SPECS	POWER SOURCE
Width: 3.9 in. (10 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Height: 9.9 in. (25.1 cm)	CHARGING INFO
Depth: 3.2 in. (8 cm)	Run Time: 90 min.
Weight: 21 oz. (595 g)	Charge Time: 120 min.
CARTON SPECS	
24 pcs per carton	
Width: 12.4 in. (31.5 cm)	
Height: 13 in (33 cm)	
Length: 20.3 in. (51.6 cm)	
Weight: 13.4 lbs. (6.1 kg)	



## REFLEXX™ RABBIT 2

The unique spring-like hooked design of the Reflexx™ Rabbit 2 is more than just for looks—it's easily maneuverable and designed to be reactionary to your movements. The highly flexible design allows you to position and angle the massager at a multitude of angles, reaching the perfect spot every time. Both your G-Spot and clitoris will be simultaneously sent into overdrive from the dual, independently controlled vibrating motors.

Want to step it up? Then take advantage of the enticing "warming mode." After all, nothing's worse than desiring some self-pleasure and getting hit with the unfriendly touch of a cold vibrator. Sit back, relax, and enjoy the (literal) warm embrace of your vibrator, even on the chilliest of days.

### KEY PRODUCT FEATURES

- Dual independently controlled motors allow you to personalize your pleasure
- The unique, spring-like hooked design is easily maneuverable and reactionary—applying the right amount of pressure to stimulate the G-Spot and clitoris simultaneously
- Comfort Gripp™ finger holder for easy, no-slip control
- Warming mode brings the massager above body temperature in a few minutes
- Choose from 10 vibration options per motor—3 intensity levels and 7 vibration patterns (3 + 7)
- USB rechargeable with the included magnetic charging cord
- High-performance battery: 45-min. run time / 3-hour charge time
- Waterproof; fully submersible and bath-friendly
- Features a discretionary travel-lock • Made with hygienic silicone and ABS plastic
- Easy 3-button operation • 1-Year limited warranty

### USAGE INSTRUCTIONS

Note - When first received, the Reflexx Rabbit 2 should be locked. Follow the steps below to unlock.

**Unlock** - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz twice. Alternatively connecting to the powered charging cable will unlock it.

**Lock** - Press and hold the g-spot & warming buttons at the same time for 3 seconds. The LED will blink and the motor will buzz once.

**Power ON** - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn on the desired mode. The LED will turn on, stay lit, and will blink to indicate the current mode.

**Changing Modes / Speeds** - Press the G-Spot vibration or Clitoral vibration buttons to cycle through the 10 vibration functions. The LED will turn on, stay lit, and will blink to indicate the current mode. (Warming function has only one mode).

**Power OFF** - Press and hold the G-Spot vibration, Clitoral vibration, or warming buttons for three seconds to turn off. The LED will turn off.

### CARE INSTRUCTIONS

Spray Jimmyjane Antibacterial Cleaner on your massager before use. Wipe with a clean, dry cloth and let it air dry. Repeat after use and store in a cool, dry place.

### PACKAGE INCLUDES

(1) Reflexx™ Rabbit 2, (1) Travel Pouch, & (1) USB Charging Cord



SKU	JJ10304
UPC	840281301836



### PRODUCT INFO

PRODUCT SPECS	MODES
Length: 6.8 in. (17.2 cm)	10 Vibration Patterns (3 + 7)
Width: 4.1 in. (10.3 cm)	1 Warming Mode
Depth: 1.8 in. (4.6 cm)	IP RATING
Insertable (L): 5 in. (12.7 cm)	IPX7
Insertable (D): 1.4 in. (3.5 cm)	MATERIALS
PACKAGE SPECS	Silicone, ABS Plastic
Width: 4.7 in. (12 cm)	POWER SOURCE
Height: 10.3 in. (26.1 cm)	Rechargeable Lithium Battery (USB + Magnetic Charging)
Depth: 2.9 in. (7.3 cm)	CHARGING INFO
Weight: 17.7 oz. (502 g)	Run Time: 45 min.
CARTON SPECS	Charge Time: 4 hours
24 pcs per carton	
Width: 15 in. (31.8 cm)	
Length: 21.5 in. (54.6 cm)	
Depth: 12 in. (30.5 cm)	
Weight: 30.2 lbs (13.7 kg)	





## PRODUCT HOLDER

Easily display most Jimmyjane products with this high-quality, plastic tester stand. Featuring a recessed hole in the base, and a harness on the top, most items will easily and securely lean in this holder, allowing them to be displayed prominently. If shelf space is at a premium, this display can also be hung on most standard slat wall with the built-in hook.

### KEY PRODUCT FEATURES

- Easily holds a wide range of Jimmyjane products so you can display them next to boxes
- Features a hook on the back that will easily attach to slat wall

### CARE INSTRUCTIONS

Spot clean with antibacterial cleaner and warm water. Allow to air dry.

### PACKAGE INCLUDES

(1) Jimmyjane Product Holder



#### PRODUCT INFO

SKU	PD4003-65
UPC	603912749526



<b>CARTON SPECS</b>
1 pcs per carton
<b>MATERIALS</b>
ABS Plastic

<b>PRODUCT SPECS</b>
Length: 4.8 in. (12.2 cm)
Width: 2.6 in (6.7 cm)
Height: 4.5 in. (11.3 cm)



## JIMMYJANE PROMOTIONAL 3D HEADER SIGN

### KEY PRODUCT FEATURES

- 3D sign that helps add depth to any slat wall layout
- Uses standard slat wall hooks that you already have to support and hold up the sign
- Patent pending fold out stand-offs means no sagging when hung
- Flat-packed making it easier to ship to stores

### PACKAGE INCLUDES

(1) 90 cm 3D Sign

#### PRODUCT INFO

SKU	SIGN3DJIMMYJANE
UPC	603912747690



<b>PRODUCT SPECS</b>
Width: 35.4 in. (90 cm)
Depth: 5 in. (12.7 cm)
Height: 6 in. (15.2 cm)

<b>CARTON SPECS</b>
1 pcs per carton



FORM 2 Pro - Pink

JJ10901



FORM 2 Pro - Pink  
TESTER

JJ10901TE



FORM 2 Pro - Slate

JJ10904



FORM 2 Pro - Slate  
TESTER

JJ10904TE



Apex

JJ40026



Apex  
TESTER

JJ40026TE



Reflexx Rabbit 1

JJ10303



Reflexx Rabbit 1  
TESTER

JJ10303TE



Reflexx Rabbit 3

JJ10305



Reflexx Rabbit 3  
TESTER

JJ10305TE



Hello Touch Pro

JJ10525



Hello Touch Pro  
TESTER

JJ10525TE



Pulsus G-Spot

JJ10551



Pulsus G-Spot  
TESTER

JJ10551TE



Deimos

JJ10705



Deimos  
TESTER

JJ10705TE



Mini Chroma - Teal

JJ10513



Solis FORM 6

JJ10680





Solis Rabbit

JJ10681



8 40281 30188 1



Solis Ascend 2 Pro

JJ10684



8 40281 30191 1



Solis Kyrios

JJ10683



8 40281 30190 4



Pulsus P-Spot

JJ10552



8 40281 30186 7



Tilla

JJ10520



8 40281 30108 9



Canna

JJ10504



8 40281 30039 6



Exona

JJ10507



8 40281 30086 0



Reflexx Rabbit 2

JJ10304



8 40281 30183 6



Product Holder

PD4003-65



6 03912 74952 6



3D Sign

SIGN3DJIMMYJANE



6 03912 74769 0



# JIMMYJANE











# JIMMYJANE

JIMMYJANE USA – Los Angeles, CA 91304  
Copyright ©2023 JJ Acquisition LLC. All rights reserved.